

EOD[®] 10

ACCESSORIES



MED-ENG[®]

A BRAND OF THE SAFARILAND GROUP

EOD[®] 10 ACCESSORIES

ALL EQUIPMENT SHOWN IS COMPATIBLE WITH BOTH THE EOD 10 AND EOD 10E MODELS.



BREATHING APPARATUS (BA) FACESHIELD

Designed for use in operations involving Chemical-Biological blast threats. Integrates with many respiratory protective systems, including Self-Contained Breathing Apparatus (SCBA) and Powered Air Purifying Respirators (PAPR) models. Easily interchangeable with the standard EOD Faceshield.



CAMCORDER

Captures High Definition (720p) video during live operations and training for use as evidence, forensic analysis and training assessments. Integrates into the visor and set to the optimal vertical viewing angle. Compatible with the EOD and optional Breathing Apparatus Faceshields.



HW-300 HARDWIRE COMMUNICATIONS

When wireless communications are not possible, the HW-300 provides reliable communication between the bomb technician and the command post. Includes a digital recorder and over 120m / 400' of self-tracking, friction-controlled cable.

EOD[®] 10 ACCESSORIES

BCS 4 BODY COOLING SYSTEM

This personal cooling system keeps the user feeling refreshed and focused on the mission. Available as a 3 piece system (shirt, trousers and balaclava) or a zip-up vest. Circulates ice-chilled water over the body to remove heat very effectively. Requires access to freezing capability. Please specify 110V or 220V at time of order.



ACTIVE COOLING SYSTEM

This lightweight system chills the ambient air flowing into the EOD 10. It uses medical cold packs as its cooling source and removes heat through evaporation. It attaches to the EOD 10's fan and is powered by the suit's battery. Most effective in operating temperatures above +40C (104F).



WIRELESS COMMUNICATIONS

The EOD 10 is compatible with leading EOD radio systems. Med-Eng encourages technicians to consider the Ceotronics duplex radios based on this brand's proven effectiveness and reliability.



EOD® 10 ACCESSORIES



STEEL VISOR

Significantly enhances protection against fragmentation threats. Quickly mounted and removed by hand without tools. Star pattern viewing slits provide good visibility.

BLAST TRACKER

This blast dosimeter precisely measures overpressure experienced by a bomb technician during a blast event. Eliminates having to estimate figures. Data can be added to a user's medical records.



HYDRATION KIT

Insulated hydration kit, with flexible drinking tube, mounts to the MOLLE on the back of the EOD 10 jacket. Carries up to 2L of water to keep the user hydrated on longer missions.

TOOL POUCH

Ideal for carrying tape and tools that could be needed downrange. Clips onto the jacket and has a hook and loop closure.



HAND PROTECTORS

The Hand Protectors, including gloves, provide enhanced protection against flash heat, incendiary agents and fragmentation. Gloves available in multiple sizes.